

BLUESILTM
PRIM PM 824**Adhesion Primer for Silicone Elastomers**

Description **BLUESIL PRIM PM 824** is an adhesion primer for **room temperature vulcanising silicone elastomers**: CAF one-component (and Axad), RTV-2 two-components, on a large number of substrates as glasses, metallic and plastic surfaces.

Examples of applications **BLUESIL PRIM PM 824** is specially recommended on following substrates:

- Polar plastics materials: polyamide, polycarbonate, ABS...
- Aluminium
- Polished and unpolished Stainless Steel
- Painted steel, bi-chromated and Zinc electro-coated steels

Characteristics

Appearance	Fluid liquid
Colour	colourless
Specific gravity at 25°C, approx.	0.82
Kinematic viscosity, 25°C, mPa.s, approx.....	1
Non volatile components, %, approx.	5
Flash point (closed cup), °C, approx.	27 (Norm AFNOR T 60103)
Diluents	soluble in aliphatic hydrocarbons

Processing **BLUESIL PRIM PM 824** is particularly easy to process because it is delivered ready to use. In all cases, it must be applied to clean, dry surfaces.

BLUESIL PRIM PM 824 is applied with a dry cloth in a thin, uniform coat. In such cases of too much quantity of primer applying, white powder appears and must be eliminated in order to avoid a bad adhesion due to hydrolysis problems; the primer must be re-applied.

After applying **BLUESIL PRIM PM 824**, it is recommended to wait 15 minutes minimum to leave it time to dry, at room temperature, before applying, pouring or injecting the silicone elastomer on the primer-prepared surface. Maximum waiting time before silicone elastomer's application is 6 hours.

In order to avoid any hydrolysis problems, it is recommended not to leave the can in contact with atmospheric humidity.

Packaging **BLUESIL PRIM PM 824** is normally delivered in 500 ml can.

Storage and shelf life When stored in its original unopened packaging at a temperature of between +5°C and +30°C, **BLUESIL PRIM PM 824** can be used for up to 18 months after the date of manufacture marked on the packaging (DLU).

Comply with storage instructions and the expiry date marked on the packaging.

Past this date, Bluestar Silicones no longer guarantees that the product meets the sales specifications.

Safety Consult the safety data sheet for **BLUESIL PRIM PM 824**.

BLUESIL™ PRIM PM 824

Visit our website www.bluestarsilicones.com

 **EUROPE**

Bluestar Silicones France
 21 Avenue Georges Pompidou
 F69486 Lyon Cedex 03
 FRANCE
 Tel. (33) 4 72 13 19 00
 Fax (33) 4 72 13 19 88

 **NORTH AMERICA**

Bluestar Silicones USA
 2 Tower Center Boulevard
 Suite 1601
 East Brunswick, NJ 08816-1100
 United States
 Tel. (1) 732 227-2060
 Fax. (1) 732 249-7000

 **LATIN AMERICA**

Bluestar Silicones Brazil Ltda.
 Av. Maria Coelho Aguiar, 215
 Bloco G – 1º andar
 05804-902-Sao Paulo – SP-
 Brazil
 Tel. (55) 11 37477887

 **ASIA PACIFIC**

Bluestar Silicones Hong Kong
 Trading Co. Ltd
 29th Floor, 88 Hing Fat Street
 Causeway Bay
 Hong Kong
 Tel. (852) 3106 8200
 Fax (852) 2979 0241

Warning to the users

The information contained in this document is given in good faith based on our current knowledge. It is only an indication and is in no way binding, particularly as regards infringement of or prejudice to third party rights through the use of our products. BLUESTAR SILICONES guarantees that its products comply with its sales specifications. This information must on no account be used as a substitute for necessary prior tests which alone can ensure that a product is suitable for given use. Users are responsible for ensuring compliance with local legislation and for obtaining the necessary certifications and authorisations. Users are requested to check that they are in possession of the latest version of this document and BLUESTAR SILICONES is at their disposal to supply any additional information.